




**30" 4 BURNER DOWNDRAFT DUAL FUEL  
SLIDE-IN RANGE**

**MODELS:**

JDS1750ML0 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	11	W10432544	Griddle	26	7101P428-60	Screw, Handle
	W11602521	Owners Manual	12		Endcap	27	W10067840	Screw
	W11565454	Tech Sheet		W10557751	Stainless (Left)	28		Grill, Air
	W11615560	Dimension Guide		W10557754	Stainless (Right)		W10752102	Black
	W11602534	Quick Start Guide	13		Trim, Vent	29	W10673618	Screw
	W11604189	Control Guide		W10636529	Stainless	30	W11512127	Gasket, Console/ Cooktop
	W10817089	Downdraft Template	14	W11603774	Control, MRC2			FOLLOWING PARTS NOT ILLUSTRATED
2		Burner Cap Kit	15	W10759326	Display, Assembly		W11451578	Harness, Main
	W11352138	Black (Set of 4)	16	W10558372	Bracket, Control		W11198274	Harness, Down Draft Fan Jumper
3		Console	17		Bezel		W10598169	Harness, Display
	W11606822	Stainless		W11592977	Stainless		W10575120	Harness, Keypad
4	W11600788	Burner Kit (set of 4)	18	W10645947	Grommet		313438	Clip, Harness
5		Cooktop	19	W10854253	Bumper		W10653092	Suppressor
	W11120004	Stainless	20		Console, Lower Panel			
6	7101P485-60	Screw, Anti-Tip Kit		W10743281	Stainless			
7		Knob	21	W11379947	Bracket, Anti-Tip			
	W11592981	Stainless	22	W10162253	Brace, Corner (Left)			
8		Grate Kit		W10162252	Brace, Corner (Right)			
	W11382964	Black	23	W10557780	Bracket, Control			
9	3196169	Screw	24	W10598048	Bracket, Console (Center)			
10	W11563529	Bracket, Support (Left)	25	W11158783	Shield, Keypad			
	W11563527	Bracket, Support (Right)						


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10634238	Hinge, Receiver	22	7103P027-60	Nut	44	W11117035	Shield, Wire
2	3196560	Screw	23	3196178	Screw	45	W10162241	Channel, Rear
3		Panel, Side	24	W11544377	Light Assembly	46	W10575377	Cover, Wire
	W10162245	Black	25	W10571723	Bulb, Halogen 40 Watts	47	W11379354	Cover, Back
4	3400029	Nut	26	3400016	Screw	48	W10605411	Receiver, Slow Close Hinge
5	W11491752	Gasket, Door	27	W10586204	Sensor	49	W10554005	Rack, Heavy Duty
6	W10544952	Element, Broil	28	3196169	Screw	50	W10554006	Rack, Maximum Capacity
7	W10774342	Element, Bake	29	W10655441	Shield, Power Cord	51	W10911366	Rack, Sliding
8	W10362924	Screw	30	W10031780	Screw	52	W10624592	Cord, Power
9	W11122085	Assembly, Flue	31	W10273192	Rod, Door Switch	53	W10558277	Burner Box, Gas Downdraft
10	W10289168	Box, Burner SI	32	9758701	Spacer, Door	54	W10162257	Duct, Cooktop
11	W10341186	Front Foot Assembly	33	W10774446	Bottom, Oven	55	W10828882	Bracket, Panel (Right)
12	W10162258	Cover, Regulator	34	W11511828	Switch, Door	56	W10828883	Bracket, Panel (Left)
13	W10541959	Shield, Bake	35	W10281322	Kit, Bare Wire Adapter Block	57	W11526015	Basket, Air Fry
14	W10137382	Clip, Panel	36	W10603482	Rack, Ladder			FOLLOWING PARTS NOT ILLUSTRATED
15	W10390008	Base Rail Assembly (Left)	37	W11353932	Convection Assembly		W10289173	Insulation, Wrap
	W10390007	Base Rail Assembly (Right)	38	W10554262	Baffle, Full Convection		W10575374	Insulation, Bottom
16	W10058460	Foot, Leveling	39	W10273002	Bracket, Oven Support		4820F015-59	Insulation, Strap
17	3196548	Fuse, Thermal	40	W11379357	Bake Pan		W10162240	Insulation, Back
18	3196172	Screw	41	W10162255	Duct, Cover		7111P017-60	Clamp, Wire
19	W10035900	Support, Oven Bottom	42	W10162254	Duct, Cooling			
20	3186034	Bracket, Service	43	W11467246	Cooling Fan			
21	W10246624	Block, Terminal						


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577790	Screw	6	W10669523	Electrode, Burner	10	W10849717	Orifice (15K)
2	W11186525	Orifice, Assembly (Right Front)			(Right Rear)			(Right Front)
	W11186521	Orifice, Assembly (Right Rear)		W10669524	Electrode, Burner (Right Front)		W10849714	Orifice (9.5K) (Right Rear)
	W11186508	Orifice, Assembly (Left Rear)		W10669525	Electrode (Left Rear)		W10849722	Orifice (18K) (Left Front)
	W11186512	Orifice, Assembly (Left Front)		W10669526	Electrode, Burner (Left Front)		W10849719	Orifice (5K) (Left Rear)
3	W10949105	Bracket, Saddle Valve	7	W11602207	Manifold, Assembly	11	W10827923	Electrode, Spring (Left Front, Left Rear, Right Front, Right Rear)
4	W10552945	Tube, Supply	8	W11511818	Valve, Gas (Left Front & Right Front)	12	W11507167	Seal, Switch Shaft
5	W11596358	Harness, Spark Switch		W11511819	Valve, Gas (Left Rear)	13	W10475148	Module, Spark
				W11511824	Valve, Gas (Right Rear)	14	W10416084	Screw
			9	W10661850	Assembly, Regulator & Bracket			FOLLOWING PARTS NOT ILLUSTRATED
							W10566083	Kit, LP Conversion
							W10182767	Tie, Manifold Wire

# BLOWER PARTS






# BLOWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10661156	Enclosure, Blower	6	W10789431	Kit, Plenum Transition	11	W10661835	Plenum, Side
2	W10572225	Plenum Intake, Gas	7	W10789391	Kit, Blower Installation	12	W10702071	Retainer
3	W10572145	Plenum, Upper	8	W10810492	Kit, Blower	13	W10759311	Gasket, Blower
4	W10575379	Grease, Filter	9	W10788527	Assembly, Capacitor	14	W10642096	Adaptor, Exhaust
5	W10575393	Guard, Filter	10	W10787917	Cover, Capacitor	15	W10789390	Assembly, Plenum Support Bracket

# DOOR PARTS




# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door Handle
	W11600908	Stainless
2	9780274	Screw
3		Badge
	W11238658	Stainless
4	W10826568	Liner, Door
5	W10031790	Screw
6	W11223202	Glass, Inner
7	W11592970	Hinge, Slow Close

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8		Assembly, Outer Door
	W11618950	Stainless
9	W10541911	Bracket, Glass Upper Handle
10	W10327235	Screw
11	W10813140	Rail, Horizontal Support
12	W10031780	Screw
13	W11091878	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10813139	Rail, Vertical Support
15		Scoop, Door
	W10551024	Stainless
16	W10319024	Washer, Door
17	W11379948	Glass Spacer

# DRAWER PARTS



# DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196169	Screw
2		Panel, Drawer Front
	W10602484	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10318026	Bracket, Mounting
4	8004P024-60	Spacer, Side Panel

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W11452957	Baffle, Drawer Panel
6	W10673879	Screw

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS / POLISHES
	31605	Kit, Cooktop Care
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10432539	Griddle
	W10432545	Kit, Grill TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint