

For delicious recipes, visit www.GoPresto.com



- Pressure cooker and slow cooker in one handy appliance.
- Fast and easy, just set and the rest is automatic.
- Settings for high pressure, low pressure, slow cook, brown, sauté, and keep warm.







Locking cover, pot, cooking rack, and instructions.



Easy to clean! Removable pot with nonstick surface, inside and out.

Dishwasher safe.



Quick pressure release valve and cover lock.

- Nineteen programmed settings including 12 pressure cooking presets for meat, fish, poultry, vegetables, rice, multigrains, beans, soup, stew, and desserts.
- **Cooks up to 70% faster** than ordinary cooking methods. Saves time, energy, and money!
- Automatically maintains the proper pressure while cooking then reduces the pressure and switches to keep warm when cooking time is complete.
- **Digital controls plus an LED display** that counts down remaining cooking time.
- **Eight built-in safety features** including a cover locking system that allows pressure to build only when the cover is securely closed and prevents the cover from being opened until pressure is safely reduced.

120 volts AC, 1000 watts Stock No. 02					.02141
Out o	f Box:	Width	Depth	Height	Weight
		13.00″	11.93″	12.50″	10.25 lb
Single Carton: UPC# 075741021416					
Qty	Cube	Width	Depth	Height	Weight
1	1.36	13.31″	12.56″	14.06″	12.72 lb
Master Pack: Master pack quantity is a single unit. See above specifications.					