



*ASSEMBLY INSTRUCTIONS  
COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**905468  
CH AISE**

**ITEM : 905468**



**ASSEMBLY INSTRUCTIONS**


**ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



**WARNING!**

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



**ASSEMBLY TIME**

**15 MINUTES**

**PARTS IDENTIFICATION**

**A SEAT  
1PC**



**B FRONT LEG 2PCS**





**C BACK LEG 2PCS**




ITEM : 905468

ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



STEP 3



# PRODUCT/PART DIMENSIONS

