




## **ELECTRIC WALL OVEN**

### **MODELS:**

MOED6027LZ00 (Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10655463	Bracket, Blower (Left)	19	W10728475	Gasket, Rubber
	W11555306	Owner's Manual		W10655462	Bracket, Blower (Right)			FOLLOWING PARTS NOT ILLUSTRATED
	W11553924	Quick Start Guide						
	W11604693	Tech Sheet	11	4451758	Block, Foam		W11476030	Harness, Main
2		Assembly, Control Panel (Includes Overlay)	12	W10752316	Interface (Maxwell), User Board		W11264646	Harness, Door Latch
	W11467626	Stainless	13	W11179509	Tray, Electronic		W10409840	Harness, EOL (MRC)
3	W11556518	Control, Maxwell	14	W11166802	Divider, Chassis Back		W11249912	Harness, Signal
4	W10874478	Relay, Power (12V DC Coil)	15	W10351295	Bumper		W11233570	Harness, Console
5	W11397930	Blower	16	W11244469	Cover, Top Front 27 IN Chassis		W10655464	Bracket, Harness
6	7101P403-60	Screw	17	W11244459	Cover, Top Back 27 IN Chassis		313438	Clip, Harness
7	W11533682	Cover, WIFI	18	W11162062	Gasket, Rubber (652 MM)		4450800	Screw, Grounding
8	7101P426-60	Screw					4448664	Clamp, Conduit
9	W11339492	Screw (Black)					W11394923	Bag, Hardware


# OVEN PARTS



# OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10254050	Screw	22		Trim, Bottom Vent	38	W11167419	Cover, Suction (Left)
2	W11085298	Tube, Vent		W11560860	Black		W11186675	Cover, Suction (Right)
3	W11100732	Receiver, Hinge (Upper)	23	W11135135	Support, Air Channel	39	W11256421	Cover, Top Back Exhaust
4	W11558603	Spacer, Base	24	W11390667	Spacer, Chassis Bottom Duct	40	W11256420	Base, Top Back Exhaust
5	W11132456	Latch, Motorized	25	W11166315	Bumper and Screw	41	W11256431	Cover, Lower Back Exhaust
6	W11244456	Top, Chassis	26	8285593	Cover, Connector	42	W11256430	Base, Lower Back Exhaust
7	W11205574	Assembly, Oven Light	27	7101P426-60	Screw	43	W11256432	Deflector, Lower Back Exhaust
8	W11245118	Foot, Base	28	W11256423	Base, Vent Exhaust	44	W11211345	Foam, U-Bracket
9	W10904163	Deflector, Blower	29	W11245114	Foot, Chassis (Left)	45	W11344645	Hat Bracket, Vent
10	W11134657	Duct, Lower Chassis Back		W11245116	Foot, Chassis (Right)	46	W11404000	Screw
11	W11608109	Gasket, Cavity	30	W11342780	Bracket, Top Front	47	W11239070	Receiver, Hinge (Left)
12	W11256424	Cover, Vent Exhaust	31	W11186652	Bracket, U-Shape		W11239072	Receiver, Hinge (Right)
13	W11165274	Side, Chassis	32	W11235483	Vent, Center 27"			(Lower)
14		Back, Chassis (Not Serviced)	33	W11334858	Vent, Top 27 in			FOLLOWING PARTS NOT ILLUSTRATED
15	W10472386	Lens, Light	34	W11165250	Duct, Chassis Back (Upper)			
16	W11346074	Probe, Sensor	35	W11249635	Screw			
17	W10472384	Bulb, Light	36		Liner, Oven (Not Serviceable)			
18	4449751	Thermostat (TOD)	37	W11235460	Cover, Side trim (Left)		W11244474	Insulation, Wrap
19	W11244454	Base, Chassis		W11235461	Cover, Side Trim (Right)		W11244475	Insulation, Back
20		Assembly, Bottom Vent						
	W11467824	Stainless						
21	W11244446	Duct, Bottom Chassis						


# UPPER OVEN DOOR PARTS



# UPPER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	7	7101P426-60	Screw	11		Door Assembly
2	7101P375-60	Screw	8	W11296054	Hinge, Door (Left)		W11470090	Stainless
3	W11290045	Screw		W11296055	Hinge, Door (Right)	12	W10319024	Washer, Door
4	W10618123	Glass, Inner				13		Handle Assembly
5	W11302731	Spacer, Air Divider	9	3196183	Screw		W11496834	Stainless
6	W11204277	Retainer, Air Divider Glass	10	W11317731	Screw (Black)	14	W10650497	Spacer, Handle

# LOWER OVEN DOOR PARTS






# LOWER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	8	W11296054	Hinge, Door (Left)	14		Handle Assembly
2	7101P375-60	Screw		W11296055	Hinge, Door (Right)		W11496834	Stainless
3	W11290045	Screw	9	3196183	Screw	15	W10650497	Spacer, Handle
4	W10618123	Glass, Inner	10	W11317731	Screw (Black)			
5	W11302731	Spacer, Air Divider	11		Door Assembly			
6	W11204277	Retainer, Air Divider Glass		W11470090	Stainless			
7	7101P426-60	Screw	12	W10319024	Washer, Door			
			13	W11628148	Badge			

# INTERNAL OVEN PARTS



# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238160	Element, Broil	7	W11292248	Element, Bake	13	W11629505	Airfry Basket Kit
2	W10554529	Rack, Oven	8	W11398058	Convect Motor Assembly	14	W10720084	Screw
3	W10318198	Tray, Hidden Bake	9	W11433702	Nut, Acorn (LH)	15	W11251715	Plate, Convect Motor
4	7101P434-60	Screw	10	W11425715	Blade, Fan	16	W11251716	Insulation, Convect Motor
5	7101P426-60	Screw	11	W10260248	Ring, Element	17	W11398057	Cover, Convect Plate
6	W10282957	Crossbar, Hidden Bake Tray	12	W10359278	Baffle, Convection			

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
		Trim, Tall Vent
	W11570326	Black
	W11570324	Stainless
		Vent, Deflector
	W11551865	Stainless
		Trim, Bottom Vent
	W11570322	Stainless