




ELECTRIC WALL OVEN

MODELS:

WOED7027PZ00 (Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W11409842	Antenna	16	W11244469	Cover, Top Front 27 IN Chassis
	W11555306	Owner's Manual	7	W11244459	Cover, Top Back 27 IN Chassis			
	W11553919	Quick Start Guide						FOLLOWING PARTS NOT ILLUSTRATED
	W11623567	Tech Sheet	8	7101P426-60	Screw			
2		Assembly, Control Panel (Includes Overlay)	9	W11339492	Screw (Black)	W11621911		Harness, Main
	W11639723	Stainless	10	W10655463	Bracket, Blower (Left)	W11245677		Harness, Signal
3	4451758	Block, Foam		W10655462	Bracket, Blower (Right)	W11264646		Harness, Door Latch
4	W11253186	Appliance Manager, Copernicus (With Power Supply)	11	W11162062	Gasket, Rubber (652 MM)	W10562910		Harness, EOL
	W11253182	Appliance Manager, Copernicus (Without Power Supply)	12	W10728475	Gasket, Rubber	W11233570		Harness, Console
5	W11397930	Blower	13	W11179509	Tray, Electronic	4448664		Clamp, Conduit
			14	W11166802	Divider, Chassis Back	W10655464		Bracket, Harness
			15	W10351295	Bumper	313438		Clip, Harness
						4450800		Screw, Grounding
						W10487999		Clip, Harness
						W11394923		Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10254050	Screw	21	W11244446	Duct, Bottom Chassis	38	W11344645	Hat Bracket, Vent
2	W11085298	Tube, Vent	22		Trim, Bottom Vent	39	W11256421	Cover, Top Back Exhaust
3	W11100732	Receiver, Hinge (Upper)		W11560860	Black	40	W11256420	Base, Top Back Exhaust
4	W11558603	Spacer, Base	23	W11135135	Support, Air Channel	41	W11256431	Cover, Lower Back Exhaust
5	W11132456	Latch, Motorized	24	W11390667	Spacer, Chassis Bottom Duct	42	W11256430	Base, Lower Back Exhaust
6	W11244456	Top, Chassis	25	W11166315	Bumper and Screw	43	W11256432	Deflector, Lower Back Exhaust
7	W11205574	Assembly, Oven Light	26	8285593	Cover, Connector	44	W11167419	Cover, Suction (Left)
8	W11245118	Foot, Base	27	7101P426-60	Screw		W11186675	Cover, Suction (Right)
9	W10904163	Deflector, Blower	28	W11256423	Base, Vent Exhaust	45	W11342780	Bracket, Top Front
10	W11134657	Duct, Lower Chassis Back	29	W11235460	Cover, Side trim (Left)	46		Liner, Oven (Not Serviced)
11	W11608109	Gasket, Cavity		W11235461	Cover, Side Trim (Right)	47	W11239070	Receiver, Hinge (Left)
12	W11256424	Cover, Vent Exhaust	30	W11404000	Screw		W11239072	Receiver, Hinge (Right)
13	W11165274	Side, Chassis	31	W11186652	Bracket, U-Shape			(Lower)
14		Back, Chassis (Not Serviced)	32	W11235483	Vent, Center 27"			FOLLOWING PARTS NOT ILLUSTRATED
15	W10472386	Lens, Light	33	W11334858	Vent, Top 27 in			
16	W11346074	Probe, Sensor	34	W11165250	Duct, Chassis Back (Upper)			
17	W10472384	Bulb, Light	35	W11245114	Foot, Chassis (Left)			
18	4449751	Thermostat (TOD)		W11245116	Foot, Chassis (Right)			
19	W11244454	Base, Chassis	36	W11211345	Foam, U-Bracket		W11244474	Insulation, Wrap
20		Assembly, Bottom Vent	37	W11249635	Screw		W11244475	Insulation, Back
	W11467824	Stainless						


UPPER OVEN DOOR PARTS



UPPER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	7	7101P426-60	Screw	11		Door Assembly
2	7101P375-60	Screw	8	W11634520	Hinge, Door (Left)		W11499375	Stainless
3	W11290045	Screw		W11634521	Hinge, Door (Right)	12	W10319024	Washer, Door
4	W10618123	Glass, Inner				13		Handle Assembly
5	W11302731	Spacer, Air Divider	9	3196183	Screw		W11532601	Stainless
6	W11204277	Retainer, Air Divider Glass	10	W11317731	Screw (Black)			


LOWER OVEN DOOR PARTS



LOWER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	7	7101P426-60	Screw	11		Door Assembly
2	7101P375-60	Screw	8	W11634520	Hinge, Door (Left)		W11499375	Stainless
3	W11290045	Screw		W11634521	Hinge, Door (Right)	12	W10319024	Washer, Door
4	W10618123	Glass, Inner		3196183	Screw	13	W10884775	Badge
5	W11302731	Spacer, Air Divider	9			14		Handle Assembly
6	W11204277	Retainer, Air Divider Glass	10	W11317731	Screw (Black)		W11532601	Stainless

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238160	Element, Broil	7	W11292248	Element, Bake	13	W10906658	Screw
2	W10317431	Rack, Oven	8	W11398058	Convect Motor Assembly	14	W10720084	Screw
3	W10318198	Tray, Hidden Bake	9	W11433702	Nut, Acorn (LH)	15	W11251715	Plate, Convect Motor
4	7101P434-60	Screw	10	W11425715	Blade, Fan	16	W11251716	Insulation, Convect Motor
5	7101P426-60	Screw	11	W10260248	Ring, Element	17	W11398057	Cover, Convect Plate
6	W10282957	Crossbar, Hidden Bake Tray	12	W10359278	Baffle, Convection	18	W11629505	Airfry Basket Kit

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORY PARTS
		Trim, Tall Vent
	W11406624	Stainless Assembly, Bottom Vent
	W11369893	Black
	W11369891	Stainless