




## **GAS RANGE**

### **MODELS:**

JDS1450ML0 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Set, Grate	20		Panel, Lower Console
	W10665259	Instructions, Installation		W11188538	Black		W10565662	Stainless
	W11602520	Owners Manual	9	3196169	Screw	21	W11379947	Bracket, Anti-Tip
	W11565455	Tech Sheet	10	W11563529	Bracket,Support (Left)	22	W10162253	Brace, Corner (Left)
	W11618459	Dimension Guide		W11563527	Bracket, Support (Right)		W10162252	Brace, Corner (Right)
	W11604188	Control Guide	11	W10598048	Bracket, Console (Center)	23	W11512127	Gasket, Console/ Cooktop
	W11602533	Quick Start Guide	12		Endcap	24	W10558372	Bracket, Control
2		Burner Cap Kit		W10557751	Stainless (Left)	25	W10432544	Griddle
	W11367440	Black (Set of 3) (Left Rear, Right Front & Right Rear)		W10557754	Stainless (Right)	26	W11158783	Shield, Keypad
3		Console	13		Trim, Vent			FOLLOWING PARTS NOT ILLUSTRATED
	W11606821	Stainless		W10636529	Stainless		W11457137	Harness, Main
4	W11367105	Burner Kit (Set of 5)	14	W11603773	Control (MRC2)		W10575120	Harness, Keypad
5		Cooktop	15	W10759324	Assembly, Display		W10598169	Harness, Display
	W11316217	Stainless	16	W10557780	Bracket , Control		W11172530	Harness, Bake Drawer
6	7101P485-60	Screw, Anti-Tip Kit	17		Bezel		313438	Clip, Harness
7		Knob		W11592977	Stainless		3196520	Clip, Wire
	W11592981	Stainless	18	W10645947	Grommet			
			19	W10854253	Bumper			


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10634238	Hinge, Receiver	21	W10245259	Block, Terminal	43	W11467246	Cooling Fan
2	W10162258	Cover, Regulator	22	W10624592	Cord, Power	44	W10162260	Shield, Heat
3		Panel, Side	23	3196178	Screw	45	W10162241	Channel, Rear
	W10162245	Black	24	W11544377	Light Assembly	46	W10575377	Cover, Wire
4	3400029	Nut	25	311255	Bulb, Oven Light	47	W11379354	Cover, Back
5	W11491752	Gasket, Door	26	3400016	Screw	48	W10603482	Rack, Ladder
6	W10544952	Element, Broil	27	W10586204	Sensor	49	W10554005	Rack, Heavy Duty
7	W10774342	Element, Bake	28	3196169	Screw	50	W10554006	Rack, Maximum Capacity
8	W10362924	Screw	29	W10655441	Shield, Power Cord			
9	W11122085	Assembly, Flue	30	W10031780	Screw	51	W10911366	Rack, Sliding
10	W10289168	Box, Burner SI	31	W10273192	Rod, Door Switch	52	W10554262	Baffle, Full Convection
11	W10341186	Front Foot Assembly	32	9758701	Spacer, Door	53	W10813366	Shield, Wire
12	W11320442	Gas Box Burner	33	W10774446	Bottom, Oven	54	W11526015	Basket, Air Fry
13	W10541959	Shield, Bake	34	W11511828	Switch, Door			Following Parts Not Illustrated
14	W10137382	Clip, Panel	35	W10281322	Kit, Bare Wire Adapter Block		W10655489	Insulation, Wrapper
15	W10390008	Base Rail Assembly (Left)	36	W10162257	Duct, Cooktop		W10655490	Insulation, Main Back
	W10390007	Base Rail Assembly (Right)	37	W11353932	Convection Assembly		W10575374	Insulation, Bottom
16	W10058460	Foot, Leveling	38	W10605411	Receiver, Slow Close Hinge		W10655442	Insulation, Heat Shield
17	3196548	Fuse, Thermal	39	W10273002	Bracket, Oven Support		7111P017-60	Clamp, Wire
18	3196172	Screw	40	W11379357	Bake Pan		3196520	Clip, Wire
19	W10035900	Support, Oven Bottom	41	W10162255	Duct, Cover		4820F015-59	Insulation, Strap
20	3186034	Bracket, Service	42	W10162254	Duct, Cooling			


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577790	Screw	6	W10898387	Electrode, Burner	10	W10702888	Orifice (18K)
2	W11186511	Assembly, Orifice (19K)			(Left Front)			(Left Front, Power)
		(Left Front)		W10669525	Electrode		W11354862	Orifice (1.45K)
	W11186508	Orifice, Assembly			(Left Rear)			(Left Front, Simmer)
		(Left Rear)		W10669524	Electrode, Burner		W11186508	Orifice, Assembly
	W11186524	Assembly, Orifice (15K)			(Right Front & Center)			(Left Rear)
		(Right Front)		W10669523	Electrode, Burner		W10849717	Orifice (15K)
	W11186520	Assembly, Orifice (9.2K)	7	W11602206	Manifold Assembly		W10849714	Orifice (9.5K)
		(Right Rear)						(Right Front)
	W11186517	Assembly, Orifice (8K)	8	W11593170	Valve, Gas (Dual)		W10849715	Orifice (8K)
		(Center)			(Left Front)			(Center)
3	W10949105	Bracket, Saddle Valve		W11511819	Valve, Gas	11	W10827923	Electrode, Spring
					(Left Rear)	12	W11507167	Seal, Switch Shaft
4	W10552945	Tube, Supply		W11511818	Valve, Gas	13	W10475149	Module, Spark (5+0)
5	W11596366	Harness, Spark Switch			(Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
				W11511824	Valve, Gas			
					(Right Rear & Center)		W11397194	LP Conversion Kit
			9	W10661850	Assembly, Regulator & Bracket		W10182767	Tie, Manifold Wire

# DOOR PARTS






# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10541911	Bracket, Glass Upper Handle
2	8533988	Screw
3		Assembly, Outer Door
	W11618953	Stainless
4	W10826568	Liner, Door
5	W11223202	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Assembly, Door Handle
	W11600908	Stainless
7	W10327235	Screw
8	W10319024	Washer, Door
9		Scoop, Door
	W10551024	Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W11592970	Hinge, Slow Close
11	W10813140	Rail, Horizontal Support
12	W10813139	Rail, Vertical Support
13		Badge
	W11238658	Stainless
14	W11379948	Glass Spacer

# DRAWER PARTS



# DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Drawer Handle	7	8533988	Screw	17	W10541947	Panel, Front Inner
	W11600908	Stainless	8	W10634260	Enclosure, Warming	18	W10729897	Fuse, Thermal
2	W10757442	Drawer,Bake	9	W10727084	Cover, Gas Valve	19	W10602493	Rack, Bake Drawer
3	W10550987	Seal, Drawer	10	W10634259	Cover, Wire			
4		Panel, Drawer Front	11	W10720530	Sensor			
	W10541958	Stainless	12	W10541944	Element, Bake			
5	W10921904	Slide, Drawer (Left)	13	W10551019	Cover, Side			
	W10921905	Slide, Drawer (Right)	14	3823F017-45	Spacer, Handle			
6	3196169	Screw	15	W10551018	Insulation, Drawer Front			
			16	W10550982	Insulation, Drawer			

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	WA906B	Scraper, Cooktop
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10432545	Kit, Grill
	W10432019	Alt Cleaning Kit Assembly, Trim (Includes Blind Threaded Insert) (5/8")
	W10675026	Black
	W10675027	White
	W10675028	Stainless (1 1/8")
	W10731886	Black
	W10731885	White
	W10731887	Stainless Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless