


BOX #1


A. UPH SHELTER HEADBOARD



1PC

BOX #2


B. LEFT SHELTER SIDE RAIL 1PC C. RIGHT SHELTER SIDE RAIL 1PC BED HARDWARE BOX



BOX #3

D. STORAGE FOOTBOARD 1PC E. STORAGE LEG 2PCS


F. CENTER SLAT G. LEG SUPPORT 1PC 3PCS



BOX #4

H. SLAT ROLL

1SET



ASSEMBLY COMPLETE



HARDWARE PACKED IN BOX #2

1	WOOD SCREW (8X30mm)	3	9 PCS
2	ALLEN BOLT (6X40mm)		14 PCS
3	ALLEN KEY (L4)		1 PC

YOUR BOX MAY CONTAIN EXTRA HARDWARE










NOT PROVIDED


UPDATED: SEPTEMBER 2ND, 2022









STEP 2:





STEP 3:



















INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each leg support (**G**) and storage leg (**E**).

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.


UPDATED: SEPTEMBER 2ND, 2022

MAINTENANCE INSTRUCTION:

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it.
 Dragging can damage the leg support.
- Readjust levelers after moving your bed.
- Periodically tighten all fittings, which can loosen over time.




BOX #1




BOX #2

B. LEFT SHELTER SIDE RAIL 1PC C. RIGHT SHELTER SIDE RAIL 1PC BED HARDWARE BOX




BOX #3

D. STORAGE FOOTBOARD 1PC
E. STORAGE LEG 2PCS
F. CENTER SLAT 1PC
G. LEG SUPPORT 3PCS



BOX #4

H. SLAT ROLL 1SET



ASSEMBLY COMPLETE



HARDWARE PACKED IN BOX #2

1	WOOD SCREW (8X30mm)	3	9 PCS
2	ALLEN BOLT (6X40mm)		14 PCS
3	ALLEN KEY (L4)		1 PC

YOUR BOX MAY CONTAIN EXTRA HARDWARE








NOT PROVIDED


UPDATED: SEPTEMBER 2ND, 2022









STEP 2:





STEP 3:















STEP 7:





INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each leg support (**G**) and storage leg (**E**).

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.

UPDATED: SEPTEMBER 2ND, 2022

MAINTENANCE INSTRUCTION:

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it.
 Dragging can damage the leg support.
- Readjust levelers after moving your bed.
- Periodically tighten all fittings, which can loosen over time.

