




SAMSUNG

Unpacking and Installation Guide



USB	USB ↔	OPTICAL	
ARC	HDMI (eARC)	LAN	
	HDMI	ANT	



Scan this QR code with your smart phone to see helpful videos.





1 **55"**

65"

2 **3**


4





	A	B	C	D	E	F	G	H
55S85D	48.3 inches (1225.7 mm)	27.8 inches (705.6 mm)	1.3 inches (33.9 mm)	30.5 inches (774.4 mm)	9.3 inches (235.3 mm)	54.6 inches	28.7 lbs (13.0 kg)	29.5 lbs (13.4 kg)
65S85D	57.0 inches (1446.6 mm)	32.7 inches (829.7 mm)	1.3 inches (33.9 mm)	35.3 inches (897.8 mm)	10.4 inches (263.3 mm)	64.5 inches	38.4 lbs (17.4 kg)	39.2 lbs (17.8 kg)

*: 0-9, A-Z



	VESA A x B (mm)	C (mm)	D	E x 4	F (mm)	G (inches)	H (inches)	I (inches)
55S85D	300 x 200	19-21	C + ★	M8	1.25	12.5	18.2	7.4
65S85D			C + ★	M8	1.25	17.4	22.6	7.4

*: 0-9, A-Z

★ : Wall-Mount Bracket