ITEM: 551513

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

Assembly Instruction

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Warning !

1. Do not attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and intended for commercial establishment.

PARTS IDENTIFICATION

A		OTTOMA	1PC
B		LEG	4PCS

ITEM: 551513

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



STEP 3