

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life





COASTERFURNITURE.COM

### ITEM: 205892 ASSEMBLY INSTRUCTIONS



#### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



#### ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A NIGHTSTAND



1PC

#### B BUN FOOT

4PCS


PAGE 2 OF 3

COASTERFURNITURE.COM


# ITEM:205892 ASSEMBLY INSTRUCTIONS



### <u>STEP 1</u>



STEP 2



### STEP 3 COMPLETE



PAGE 3 OF 3



COASTERFURNITURE.COM

