# OUTSIDE

CHARGING YOUR KEYBOARD

• When the battery is low, the power indicator will flash green. Connect the keyboard to a computer or USB wall adapter using the included USB-C charging cable.

• Charge the keyboard for 2 to 3 hours, or until the red charging LED light turns green. The keyboard can be used either wired or wirelessly while charging.

WIRED MODE

• Press Fn + ⏏ to activate the wired mode when USB-C cable is connected. The power LED light turns green. Press Fn + ✳1~3 button to switch back to Bluetooth mode.

WIRED MODE   BLUETOOTH MODE

HOT KEY FUNCTION & SUPPORT TABLE:

	MAC OS FUNCTION	iOS FUNCTION
☀	Decrease Display Brightness	Decrease Brightness
☀	Increase Display Brightness	Increase Brightness
🔍	Spotlight Search	Spotlight Search
▢	App Switcher	App Switcher (iPad only)
☼	Decrease Keyboard Backlit	Decrease Keyboard Backlit
☼	Increase Keyboard Backlit	Increase Keyboard Backlit
◀◀	Previous Track	Previous Track
▶❙	Play / Pause	Play / Pause
▶▶	Next Track	Next Track
🔇	Mute	Mute

	MAC OS FUNCTION	iOS FUNCTION
🔉	Volume Down	Volume Down
🔊	Volume Up	Volume Up
⏏ USB	Eject	Activate Virtual Keyboard
🔒	Fn Lock	Fn Lock

Safety Instructions

Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed

1. Keep away from microwave radiation source
2. Do not place heavy objects on this product
3. No dropping and bending
4. Keep away from oil, chemical, or organic solvents

FAQS

• **Can I use this as a wired keyboard?**
A: Yes, the Slim X1 Keyboard includes USB wired connectivity. Pressing the "FN + EJECT" keys will activate the USB wired mode for the keyboard.

• **Does the keyboard come with different color light options?**
A: Unfortunately, the keyboard is only equipped with a white backlight. However, you are able to cycle through 10 different brightness options.

• **How long does the battery last on a full charge?**
A: The battery life of the keyboard can vary depending on the level of the backlight brightness but the longest the keyboard can last on a full charge is approximately 80 hours.

• **Why did my keyboard backlight dim/turn off automatically?**
A: The backlight will automatically dim after one minute of non-usage. It will also turn off automatically once it reaches low-power mode.
(Green flashing LED = Low-Power Mode)

S∧TECHI

SLIM X1 BLUETOOTH
BACKLIT KEYBOARD

USER MANUAL

INSIDE

PACKAGING CONTENT

SLIM X1 BLUETOOTH BACKLIT KEYBOARD
USB-C CHARGING CABLE
USER MANUAL

SPECIFICATIONS

MODEL	ST-BTSX1M
DIMENSIONS	11.14" x 4.5" x 0.39"
WEIGHT	29.4g
WIRELESS CONNECTIVITY	Bluetooth

SYSTEM REQUIREMENTS

|	
BLUETOOTH VERSION	3.0 or later
MACOSX	v10.4 or later
IOS	Bluetooth enabled

FUNCTIONS

Note: The keyboard layout function is based on iOS and MAC OS default settings. The output might differ for different OS.

1. ON/OFF SWITCH
2. POWER/CHARGING LED INDICATOR
3. FN LOCK LED INDICATOR
4. MEDIA / FUNCTION KEYS
5. USB-C CHARGING PORT
6. BLUETOOTH DEVICE KEYS WITH LED INDICATOR
7. CAPS LOCK LED INDICATOR
8. FN KEY

ON / OFF

• To turn the Keyboard on or off, move the switch on the top of the device to the "on" position. The power indicator turns green for ~ 3 seconds and then turns off.

PAIRING YOUR DEVICES

• Press and hold Fn Key and one of Bluetooth Keys for ~3 seconds to assign a device to it. White LED Light should start Blinking.

• On the host device, look for "Slim X1 Keyboard" in the Bluetooth Setting, choose "Connect" to pair. The white LED will stop blinking, indicating a successful pairing. Repeat process to add up to 3 Bluetooth devices.

Note:
1. After 30 minutes non-operation, the keyboard will go to sleep mode. Please press any key to wake up.
2. Switch between devices by pressing Fn + 1❶, 2❷, and 3❸ to switch devices.
3. For buttons F1 ~ F12 press the "Fn" key with the key to enable the function.

LED INDICATORS

• **On/Off** - turns green for 4s and turns off.
• **Low Battery** - flashes green when it's low battery.
• **Charging** - turns red when it's charging.
• **Fully Charged** - turns green and stays green.

POWER / CHARGING LED INDICATOR

• **Press** [fn] + [esc]

To swap between Media keys and F-Keys. The white LED light gets brighter indicating FN lock is enabled.

FN LOCK LED INDICATOR

BACKLIT

• There are 10 backlight levels. You can change the backlight levels at any time by pressing ☼ ☼

Note: The backlit turns off when the keyboard battery is low.