




ELECTRIC RANGE

MODELS:

JIS1450ML0 (Stainless)


COOKTOP AND DUCT PARTS



COOKTOP AND DUCT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W10558372	Bracket, Control	18	W11636878	Control, MRC2
	W11637353	Use and Care Guide	10	7101P485-60	Screw, Anti-Tip Kit	19	W10645947	Grommet
	W11637366	Tech Sheet	11	W11379947	Bracket, Anti-Tip	20	W11610960	Assembly, Induction Side Duct
	W11637355	Quick Start Guide	12	W10162253	Brace, Corner (Left)	21	W10598048	Bracket, Console (Center)
	W11644568	Dimension Guide		W10162252	Brace, Corner (Right)	22	W10612719	Gasket, Console and Cooktop
2		Panel, Lower Console	13	W10289169	Support, Cooktop (Right)	23	W10557780	Bracket, Control
	W10743281	Stainless		W10289170	Support, Cooktop (Left)	24	W11158783	Shield, Keypad
3	3196178	Screw	14		Vent, Trim Top			FOLLOWING PARTS NOT ILLUSTRATED
4		Cooktop		W10636529	Stainless		W11631333	Harness, Main
	W11625482	Black			Endcap		W11172426	Harness, Display
5	W11616082	Spring (Cantilever)	15	W10557751	Stainless (Left)		W10575120	Harness, Keypad
6	W11610945	Duct, Recirculation Plate (Left)		W10557754	Stainless (Right)			
	W11610944	Duct, Recirculation Plate (Right)	16		Console			
7	W11610925	Pan, Induction (Lower)		W11633374	Stainless			
8	W10759326	Display, Assembly	17	W10664705	Bumper			


INDUCTION ASSEMBLY PARTS



INDUCTION ASSEMBLY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11683059	User, Interface	5	W11683054	Element, Induction (Right Front)	8	W11683057	Assembly, Induction Module
2	W11683058	Fan, Cooling						
3	W11683061	Locking Pin, User Interface	6	W11683056	Element, Induction (Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
4	W11683055	Element, Induction (Left Front and Left Rear)	7	W11683063	Strain Relief, Cable		313438	Clip, Harness
							W11683062	Harness, UI to Module
							W11615923	Harness, Induction Cooktop


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10634238	Hinge, Receiver	22	W10624592	Cord, Power	44	W10162260	Shield, Heat
2	W10362924	Screw	23	3196178	Screw	45	W10162241	Channel, Rear
3		Panel, Side	24	W11544377	Light Assembly	46	W10162248	Cover, Wire
	W10162245	Black	25	7407P103-60	Bulb, Light	47	W11379354	Cover, Back
4	3400029	Nut	26	3400016	Screw	48	W10603482	Rack, Ladder
5	W11491752	Gasket, Door	27	W10586204	Sensor	49	W10554005	Rack, Heavy Duty
6	W10544952	Element, Broil	28	3196169	Screw	50	W11661815	Basket, Airfry
7	W10774342	Element, Bake	29	W10655441	Shield, Power Cord	51	W11510561	Barrier Rail, Rubber (Front Left)
8	W10362924	Screw	30	W10554262	Baffle, Full Convection		W11510562	Barrier Rail, Rubber (Front Right)
9	W11122085	Assembly, Flue	31	W10273192	Rod, Door Switch			
10	W10289168	Box, Burner SI	32	9758701	Spacer, Door	52	W10828883	Bracket, Panel (Left)
11	W10341186	Front Foot Assembly	33	W10774446	Bottom, Oven		W10828882	Bracket, Panel (Right)
12	W10067840	Screw	34	W11511828	Switch, Door			FOLLOWING PARTS NOT ILLUSTRATED
13	W10541959	Shield, Bake	35	W10281322	Kit, Bare Wire Adapter Block	W10289173		Insulation, Wrap
14	W10137382	Clip, Panel	36	W10911366	Rack, Sliding	W10575374		Insulation, Bottom
15	W10390008	Base Rail Assembly (Left)	37	W11353932	Convection Assembly	4820F015-59		Insulation, Strap
	W10390007	Base Rail Assembly (Right)	38	W10605411	Receiver, Slow Close Hinge	W10655490		Insulation, Main Back
16	W10058460	Foot, Leveling	39	W10273002	Bracket, Oven Support	W10655442		Insulation, Heat Shield
17	3196548	Fuse, Thermal	40	W11379357	Bake Pan	7111P017-60		Clamp, Wire
18	3196172	Screw	41	7103P027-60	Nut			
19	W10035900	Support, Oven Bottom	42	W10818358	Shield, Wire			
20	3186034	Bracket, Service	43	W10554006	Rack, Maximum Capacity			
21	W10246624	Block, Terminal						

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner, Door Scoop
	W10551024	Stainless
2		Assembly, Door Handle
	W11600908	Stainless
3		Badge
	W11238658	Stainless
4	W10826568	Liner, Door
5	W10031790	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W11223202	Glass, Inner
7	W11592970	Hinge, Slow Close
8	W10541911	Bracket, Glass Upper Handle
9	W10541883	Hinge, Support Rail
10	W10319024	Washer, Door
11	W10813140	Rail, Horizontal Support
12	W10031780	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	8533988	Screw
14		Assembly, Outer Door
	W11618950	Stainless
15	W11379948	Glass Spacer
16	W11440161	Bottom, Door Cover
17	W10813139	Rail, Vertical Support
18	W10327235	Screw
19	9780274	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	2	3400882	Screw	4	W10318026	Bracket, Mounting
	W10602484	Stainless	3	W11452957	Baffle, Drawer Panel	5	8004P024-60	Spacer, Side Panel

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit and Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS AND POLISHES
	31605	Kit, Cooktop Care
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10432539	Griddle
	W10432545	Kit, Grill TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless