

AMANA®


GAS RANGE

MODELS:

AGR6303MMB0 (Black)

AGR6303MMW0 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	98014544	Wire, Ground	17	W10515453	Assembly, Burner (6K)
	W11508819	Instructions, Installation	9	98013389	Bumper, Cooktop			(Right Rear)
	W11508815	Owners, Manual	10	98006726	Screw (Black)	18	3400701	Screw
		Wire, Diagram		98005658	Screw (Stainless)			FOLLOWING PARTS NOT ILLUSTRATED
2		Cooktop	11		Cap, Burner		W11465032	Harness, Main
	W10818512	Black		98017461	Black		98005896	Clip, Wire
	W10818513	White			(Left Front, Left Rear, & Right Front)		W11492747	Insulation, Manifold
3		Panel, Manifold	12	8534079	Screw, Ground		3391018	Tie, Cable
	W11578465	Black	13	W10636224	Burner, Standard		98015022	Bushing, Snap
	W11578464	White			(Left Front, Left Rear, & Right Front)			
4		Knob, Burner	14	W10613666	Bracket, Anti-Tip			
	W11558936	Black	15	7101P485-60	Screw, Anti-Tip Kit			
	W11541410	White	16		Burner Cap, Auxiliary			
5	98007225	Screw		W10169985	Black			
6		Grate, Burner			(Right Rear)			
	W10578251	Black						
7	98004722	Clip, Cooktop						


BACKGUARD PARTS



BACKGUARD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap (Left Hand)	3	8534079	Screw, Ground	6	W10535746	Bracket, Console Mount
	W10873109	Black	4		Panel, Control			
	W10873441	White		W11506685	Black	7	W10493726	Screw
		Endcap (Right Hand)		W11506730	White	8	W11462420	Bracket, Control
	W10873107	Black	5		Control, Electronic	9	W10535815	Bracket, Rear
	W10873438	White		W11520703	Black			
2	W10588614	Backguard, Rear		W11520702	White			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10610297	Nut	11	W10493726	Screw	20	98017349	Orifice, Natural (11.5K)
2	W10620002	Assembly, Tubing (Left Front)	12	W11562246	Harness, Switch			(Left Front)
	W10512770	Assembly, Tubing (Left Rear)	13	98014893	Valve, Oven		98017348	Orifice, Natural (9.5K)
	W10512771	Assembly, Tubing (Right Front)	14	W10278150	Clip, Ignitor			(Left Rear and Right Front)
	W10514424	Assembly, Tubing (Right Rear)	15	W11509757	Valve, Saddle (Left Front)		W10170506	Orifice, Natural (5K) (Right Rear)
3	W10122103	Bracket, Surface Burner		W11509554	Valve, Saddle (Left Rear and Right Front)	21	W11208965	Igniter, Hot Surface
4	W10622750	Cable, Spark (Black)		W11509769	Valve, Saddle (Right Rear)	22	W10574737	Bracket, Valve
5	W11281166	Java Tech Spark Module 4 POS	16	98017517	Screw	23	W10512963	Tubing (Regulator to Oven Valve)
6	98007225	Screw	17	W11509626	Assembly, Manifold	24	W10146346	Screw
7	W10619922	Tube 3/8" Manifold To Reg	18		Ignitor, Top	25	98007410	Bracket, Regulator
8	98005659	Screw		W10209656	Black			FOLLOWING PARTS NOT ILLUSTRATED
9	98013634	Screw		W10209657	Natural			
10	W10650358	Oven Burner Asm-US Electronic	19	W10633327	Regulator		W11557685	Kit, LP Conversion


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10675411	Box, Flue	10	W10058460	Foot, Leveling (Rear)	22	W10493726	Screw
2	W10554269	Socket - Oven Light				23	W10670196	Spread, Flame (Bake)
3	W10164110	Shield, Insulation	11	W10620410	Assembly, Oven Bottom	24	98006726	Screw (Black)
4		Panel, Side	12	W10577312	Support, Side Panel	25	W11510655	Clip, Tubing
	W10666212	Black (Left)	13	W10670197	Deflector, Oven	26	W11492823	Cover
	W10666211	Black (Right)	14	W10520269	Rail, Base	27	W10788320	Bulb, Light
	W10666176	White (Left)	15	W10545322	Bracket, Manifold	28	98008545	Screw (Black)
	W10666141	White (Right)	16	W11172758	Bracket, Foot	29	W10640762	Cord, Power
5	98005502	Clip, Oven Botton	17	W10549293	Safety Valve, Rear Cover			FOLLOWING PARTS NOT ILLUSTRATED
6	W10902689	Counterweight	18	W10550642	Rack, Oven	W11492324		Insulation, Wrap
7	98015363	Support, Rear	19	W10181986	Sensor, Oven	W11048974		Insulation, Back
8	W10532560	Side Panel, Support	20	W10327222	Counter Support-Hinge	W10613818		Insulation, Upper
9	W10650383	Foot Leveling & Foot Base (Front)	21	W10535778	Seal, Oven	W10212526		Insulation
						98004294		Wire Tie, Insulation
						W11506534		Insulation,Flue

BROILER PARTS




BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11620318	Baffle, Base
2	W10119413	Screw
3	98008545	Screw (Black)
4	W10155121	Screw
5	W10624273	Cover, Broiler Left
	W10624275	Cover, Broiler Right
6	W10647966	Hinge
7	W10605426	Panel, Side
8	98006726	Screw (Black)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10446851	Liner, Broiler Drawer
10	W10682676	Back Cover, Broiler
11	W10216478	Insulation, Broiler Door
12		Panel, Broiler Door
	W10874825	Black
	W10874828	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Handle, Broiler Door
	W10535809	Black
	W10498563	White
14	98004052	Bumper, Door
15	98004993	Screw

DOOR PARTS



DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	98006726	Screw (Black)
2	W10292266	Seal, Inner Door
3	W10544145	Upper Trim, Oven Door
4		Trim, Side
	W11184558	Left
	W11184560	Right
5	W10146346	Screw
6	W10535788	Hinge, Oven Door (Black & White Models)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7		Glass, Outer Door
	W11541719	Black
	W11488036	White
8	W11569276	Handle, Support Bracket
9	W11528109	Glass, Inner
10		Handle, Oven Door
	W11492899	Black
	W11492898	White
11	98008699	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10493726	Screw
13		Bracket, Glass Door Hold
	W10811550	Black
	W10823829	White
14		Badge
	W10846751	Black
	W10849465	White

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	98012220	Kit, Door Pin